




# 3DM2210

## 三相开环步进驱动器使用手册

### OPEN-LOOP 3-PHASE STEP MOTOR DRIVE User's Manual



## 目录

<b>前言/Foreword.....</b>	<b>3</b>
<b>1 概述/Overview.....</b>	<b>3</b>
1.1 产品介绍/Product Introduction.....	4
1.2 特性/Characteristics.....	4
1.3 应用领域/Application areas.....	5
<b>2 性能指标/Performance Index.....</b>	<b>5</b>
2.1 电气特性/Electrical characteristics.....	5
2.2 使用环境/Use environment.....	5
<b>3 安装/Installation.....</b>	<b>5</b>
3.1 安装尺寸/Mounting dimensions.....	5
3.2 安装方法/Installation method.....	6
<b>4 驱动器端口与接线/Driver ports and wiring.....</b>	<b>7</b>
4.1 接线示意图/Schematic diagram of wiring.....	7
4.2 端口定义/Port Definition.....	8
<b>5 拨码定义/Dial definition.....</b>	<b>13</b>
5.1 电流设定/Current setting.....	13
5.2 细分设定/Subdivision setting.....	14
5.3 功能设置/Function setting.....	14
5.4 参数自整定功能/Parameter self-tuning function .....	135
<b>6 保修及售后服务 /Warranty and after-sales service.....</b>	<b>16</b>

## 前言/Foreword

感谢您使用本公司开环步进驱动器。

**Thank you for using our open step drive.**

在使用本产品前, 请务必仔细阅读本手册, 了解必要的安全信息、注意事项以及操作方法等。错误的操作可能引发极其严重的后果。

**Before using this product, please read this manual carefully to understand the necessary safety information, precautions, and operation methods. Incorrect operation can have extremely serious consequences.**

本产品的设计和制造不具备保护人身安全免受机械系统威胁的能力, 请用户在机械系统设计和制造过程中考虑安全防护措施, 防止因不当的操作或产品异常造成事故。

**This product is designed and manufactured without the ability to protect personal safety from mechanical system threats. Users are advised to consider safety precautions during mechanical system design and manufacturing to prevent accidents caused by improper operation or product abnormalities.**

由于产品的改进, 手册内容可能变更, 恕不另行通知。用户对产品的任何改装我公司将不承担任何责任。

阅读时, 请注意手册中的以下标示:

**Due to product improvements, the contents of this manual are subject to change without notice. Our company will not be responsible for any modification of the product by the user.**

**When reading, please pay attention to the following signs in the manual:**




注意: 提醒您注意文字中的要点。



小心: 表示错误的操作可能导致人身伤害和设备损坏。

本产品经过国家强制 3C 认证, CE 认证, ROHS 认证

**This product has passed the national mandatory 3C certification, CE certification, ROHS certification**



## 1 概述/Overview

### 1.1 产品介绍/Product Introduction

3DM2210是我公司推出的高压数字式三相开环步进电机驱动器，采用最新32位DSP数字处理技术和IPM功率模块架构设计，驱动器控制算法采用先进的变电流技术和先进的变频技术，驱动器发热小，电机振动小，体积小，运行平稳。用户可以设置200~51200内的任意细分以及额定电流内的任意电流值，能够满足大多数场合的应用需要。由于采用内置微细分技术，即使在低细分的条件下，也能够达到高细分的效果，低中高速运行都很平稳，噪音超小。驱动器内部集成了参数上电自动整定功能，能够针对不同电机自动生成最优运行参数，最大限度发挥电机的性能。

3DM2210 is a new digital stepper motor driver introduced by our company. It adopts the latest 32-bit DSP digital processing technology. The driver control algorithm adopts advanced variable current technology and advanced frequency conversion technology. The driver generates less heat and the motor vibrates less, smooth operation. USERS can set 200 ~ 51200 within the arbitrary subdivision and rated current within the arbitrary current value, to meet the needs of most applications. Due to the use of built-in micro-subdivision technology, even in the conditions of low subdivision, but also can achieve high subdivision effect, low, medium and high-speed operation is very smooth, ultra-low noise. The auto-tuning function is integrated in the driver, which can automatically generate the optimal operating parameters for different motors and maximize the performance of the motors.

### 1.2 特性/Characteristics

- 全新 32 位 DSP 技术

New 32 Bit DSP Technology

- 超低振动噪声

Ultra-low vibration noise

- 内置高细分

Built-in high subdivision

- 参数上电自动匹配电机功能

Automatic parameter power-on setting function

- 变电流控制使电机发热大为降低

Variable current control greatly reduces the heat generation of the motor.

- 静止时电流自动减半

Automatic halving of current at rest

- 可驱动 3, 6 线三相开环步进电机

Can drive 3, 6wire two-phase stepping motor

- 光电隔离差分信号输入

Photoelectric isolated differential signal input

- 光电隔离，报警输出和刹车控制

Photoelectric isolation, alarm output

- 脉冲响应频率最高可达 500KHz (出厂默认 200KHz)

Impulse response frequency up to 500KHz (factory default 200KHz)

- 电压范围直流 90-360Vdc/交流 70-253Vac , 交流直流通用

Voltage Range DC 24-110VDC or AC 20-80Vac AC

- 电流设定方便，可在 1.0-10.2A 之间任意选择

The current setting is convenient and can be selected between 2.0–8.4 A

- 细分设定范围为 200–51200，其它细分可定制

sub-set range 200–51200, higher sub-customizable

- 具有过压、欠压、过流和过温等保护功能

It has the protection functions of overvoltage, undervoltage and overcurrent.

- 具有上升沿/下降沿，I/O 控制自发脉冲，单/双脉冲，电位器调速，高响应/高速低振动

It has rising/falling edge, I/O control spontaneous pulse, single/double pulse, high response/high speed and low vibration, self-test function

## 1.3 应用领域/Application areas

适合各种中小型自动化设备和仪器，例如：锂电设备、3C 电子设备、雕刻机、打标机、切割机、激光照排、雕刻机，绘图仪、数控机床、自动装配设备等。在用户期望小噪声、高速度的设备中应用效果特佳。

Suitable for all kinds of small and medium-sized automation equipment and instruments, such as: lithium battery equipment, 3C electronic equipment, engraving machine, marking machine, cutting machine, laser phototypesetting, engraving machine, plotter, CNC machine tool, automatic assembly equipment, etc. It is especially effective in applications where users expect small noise and high speed.

## 2 性能指标/Performance Index

### 2.1 电气特性/Electrical characteristics


说明 Explanation	3DM2210			
	最小值 Minimum Value	典型值 Typical Value	最大值 Maximal Value	单位 Unit
连续输出电流 Continuous output current	1.0	—	10.2	A
电源电压 (直流/交流) Power Supply Voltage (DC/AC)	90/70	110. 220Vac	360/253	Vdc/Vac
逻辑输入电流 Logic input current	6	10	16	mA
逻辑输入电压 Logical input voltage	5	5	24	Vdc
脉冲频率 Pulse Frequency	0	—	200	KHz
脉冲高电平宽度 Pulse high width	1.5	—	—	US
绝缘电阻 Insulation Resistance	100	—	—	MΩ

## 2.2 使用环境/Use environment

冷却方式 Cooling Mode		风扇或强制风冷 Natural Cooling or forced air cooling
使用环境 Service Environment	场合 Occasion	不能放在其它发热的设备旁, 要避免粉尘、油雾、腐蚀性气体, 湿度太大及强振动场所, 禁止有可燃气体和导电灰尘。 Can not be placed next to other heating equipment, to avoid dust, oil mist, corrosive gases, humidity is too large and strong vibration sites, prohibited combustible gases and conductive dust.
	温度 Temperature	-10°C ~ +50°C
	湿度 Humidity	40 ~ 90%RH
	振动 Vibration	5. 9m/s <sup>2</sup> MAX
	保存温度 Storage temperature	-20°C~60°C
使用海拔 Use Elevation		1000 米以下 Below 1000 meters
重量 Weight		0. 4KG

## 3 安装/Installation

### 3.1 安装尺寸/Mounting dimensions



## 3.2 安装方法/Installation method

驱动器的可靠工作温度通常在 60℃ 以内，电机工作温度为 80℃ 以内。

The reliable operating temperature of the driver is usually within 60°C, and the motor operating temperature is within 80°C.

建议使用时选择自动半流方式，马达停止时电流自动减一半，以减少电机和驱动器的发热。

It is recommended to use the automatic semi-flow mode when using the motor. When the motor stops, the current is automatically reduced by half to reduce the heat of the motor and the drive.

安装驱动器时请采用竖着侧面安装，使散热齿形成较强的空气对流。


Install the drive with vertical side mounting so that the heat dissipating teeth form a strong air convection.

必要时机内靠近驱动器处安装风扇，强制散热，保证驱动器在可靠工作温度范围内工作。


Install a fan near the drive when necessary to force heat dissipation to ensure that the drive works within a reliable operating temperature range.

## 4 驱动器端口与接线/Driver ports and wiring

### 4.1 接线示意图/Schematic diagram of wiring



## 4.2 刹车控制接线图



说明：1，电机刹车控制为驱动器信号端口 BK 与 COM-组成，另外，报警信号输出 ALM/P 也与 COM-组成，所以 COM-为刹车控制和报警输出的公共负端，BK 和 ALM/P 为光耦隔离 OC 射极输出。  
 2，在控制环境比较好的场合，干扰小的场合，C2 和 D2 可以不用。






## 4.3 端口定义/Port Definition

### 4.3.1 LED 灯状态指示/Lamp status indication

绿色 LED 为电源指示灯，当驱动器接通电源时，该 LED 常亮；当驱动器切断电源时，该 LED 熄灭。红色 LED 为故障指示灯，当出现故障时，该指示灯以 3 秒钟为周期循环闪烁；当故障被用户清除时，红色 LED 常灭。红色 LED 在 3 秒钟内闪烁次数代表不同的故障信息，具体关系如下表所示。

LED power indicator is green, when the drive power, the LED is lit; when the drive power is cut off, the LED is off. Fault indicator red LED, when a failure occurs, the indicator is blinking cycle to cycle 3 seconds; the user when the fault is cleared, the red LED is off. Red LED flashing number within 3 seconds represent different fault information, the specific relationship shown in the following table.

序号 No.	闪烁次数 The number of flashes	红色 LED 闪烁波形 Red LED flashes waveform	故障说明 Description of the problem
1	1	□ □ □	过流故障 (I 峰值 $\geq 25A$ ) Overcurrent fault (I peak $\geq 25A$ )

2	2		过压故障 ( $V_{dc} \geq 195V$ ) Overvoltage fault ( $V_{dc} \geq 195V$ )
3	3		欠压故障 (预留, 不建议使用) Undervoltage fault (reserved, not recommended)
4	4		缺相故障 (预留, 不建议使用) Phase missing fault (reserved, not recommended)
5	7		预留给闭环用, 跟踪误差超差故障 Tracking error overshoot fault
6	7		预留给闭环用, 编码器接线故障 Tracking error overshoot fault
7	7		预留给闭环用, 电机初始相位故障 Encoder connection fault
8	9		因电机原因驱动器损坏故障 Driver failure due to motor reason

### 4.3.2 控制信号输入端口/Control Signal Input Port

#### 控制信号接口

Control Signal interface


接口名称 Interface name	功能 Features	说明 Explanation
PUL+	脉冲正输入端 Pulse Positive Input	
PUL-	脉冲负输入端 Pulse negative input	兼容 5V-24V 电平信号, 可以单独生产只能接收 5V 信号或 24V 信号电平的接口 Compatible with 5V-24V level signals, and can independently produce interfaces that can only receive 5V signals or 24V signal levels
DIR+	方向正输入端 Directional Positive Input	
DIR-	方向负输入端 Directional negative input	
ENA+	使能正输入端 Enable Positive Input	
ENA-	使能负输入端 Enable negative input	
ALM/P	报警信号正输出端 Positive output of alarm signal	集电极开路 OC 输出, 最大上拉电平 24V, 最大输出电流 100mA, 默认为报警信号输出, 可以派生为到位信号输出 Open collector output, maximum pull up level 24V, maximum output current 100mA
BK	电机刹车控制	控制电机的刹车, 需要先去控制驱动器, 再由继电器控制电机刹车, 继电器最好使用固态继电器 To control the braking of a motor, it is necessary to first control the driver, and then control the motor braking by a relay. It is best to use a solid-state relay for the relay
COM-	报警信号和刹车控制公共负端	

#### 控制信号接口电路

A control signal interface circuit


# 用户手册/User's Manual

5–24V无需串联限流电阻  
5–24V series current limiting resistance is not required




共阳极接法  
Common anode connection

5–24V无需串联限流电阻  
5–24V series current limiting resistance is not required



共阴极接法  
Common cathode connection

5–24V无需串联限流电阻  
5–24V series current limiting resistance is not required




共阴极接法  
Common cathode connection

## 控制信号时序图

A control signal timing in FIG.

为了避免一些误动作和偏差, PUL-、DIR-和ENA-应满足一定要求, 如下图所示:

In order to avoid malfunctions and deviations, PUL-, DIR-, ENA- should meet certain requirements, and, as shown below:



注释/Comment:

- 1) t1: ENA (使能信号) 应提前 DIR 至少  $5 \mu s$ , 确定为高。一般情况下建议悬空即可;  
 t1: ENA (enable signal) DIR should advance at least  $5 \mu s$ , determined to be high. In general recommendations can be suspended;
- 2) t2: DIR 至少提前 PUL 下降沿  $1 \mu s$  确定其状态高或低;  
 t2: DIR PUL falling  $1 \mu s$  determined in advance of at least a high or low state;
- 3) t3: 脉冲宽度至少不小于  $1.5 \mu s$ ;  
 t3: at least a pulse width of not less than  $1.5 \mu s$ ;
- 4) t4: 低电平宽度不小于  $1.5 \mu s$ 。  
 t4: low level width not less than  $1.5 \mu s$ .

## 4.2.3 电源及电机输出端口/Output ports of power supply and motor

**供电与电机动力接口**

Power supply and motor power interface

接口名称 Interface name	功能 Features
ACN	直流交流共源地, 供电电压范围: 直流 90–360Vdc, 交流 70–253Vac DC/AC common source, supply voltage range: DC 90–360VDC, AC 70–253Vac
ACL	直流交流共源地, 供电电压范围: 直流 24–110Vdc, 交流 20–80Vac DC/AC common source, supply voltage range: DC 90–360VDC, AC 70–253Vac
W	三相步进电机 W 相绕组接口 Stepping motor W phase winding interface
V	三相步进电机 V 相绕组接口 Stepping motor V phase winding interface
U	三相步进电机 U 相绕组接口 Stepping motor U phase winding interface
NC	预留, 不用接任何电气 NC

电源电压在规定范围之间都可以正常工作, 驱动器最好采用隔离型变压器电源供电,

## 5 拨码定义/Dial definition

### 5.1 电流设定/The current setting

Peak	RMS	SW1	SW2	SW3	SW4
Default [RMS=1.0A]		on	on	on	on
2.10A	1.50A	off	on	on	on
2.80A	2.00A	on	off	on	on
3.50A	2.50A	off	off	on	on
4.20A	3.00A	on	on	off	on
5.00A	3.60A	off	on	off	on
5.60A	4.00A	on	off	off	on
6.20A	4.40A	off	off	off	on
6.80A	4.80A	on	on	on	off
7.40A	5.20A	off	on	on	off

8.00A	5.60A	on	off	on	off
8.50A	6.00A	off	off	on	off
8.80A	6.20A	on	on	off	off
9.30A	6.60A	off	on	off	off
9.90A	7.00A	on	off	off	off
10.2A	7.20A	off	off	off	off

驱动器有自动半流功能，当驱动器在 400ms 没有接受到脉冲后，电流静止状态为半流锁轴

注：如上电流为标准产品 3DM2210 电流，其它电流可以根据客户需求派生，能设定的电流范围为 0.5–13.5A 之间的任意值。

Note: If the current is standard product 3DM2210 current, other current can be derived according to customer demand, can set the current range between 0.5–13.5 A arbitrary value.

## 5.2 细分设定/Subdivision setting

Pulse/red and IO Table (拨码设定细分和自发脉冲的速度)

Pulse/red	SW5	SW6	SW7	SW8	IO/RPM
Default[400]	on	on	on	on	10
500	off	on	on	on	20
800	on	off	on	on	30
1000	off	off	on	on	40
1200	on	on	off	on	50
1600	off	on	off	on	60
2000	on	off	off	on	80
3200	off	off	off	on	100
3600	on	on	on	off	150
4000	off	on	on	off	200
6400	on	off	on	off	250
7200	off	off	on	off	300
10000	on	on	off	off	400
20000	off	on	off	off	550
40000	on	off	off	off	650
51200	off	off	off	off	800

注：如上细分为标准产品 3DM2210 细分，其它细分可以根据客户需求派生，能设定的细分范围为 200~51200 之间的任意值。

Note: The above subdivides into the standard product 3DM2210 subdivides, other subdivides may according to the customer demand derivation, can set subdivides the scope between 200–51200 any value.

## 5.3 功能设置/Function setting

Function

SW9:Edge sel, off=Fall (下降沿/Falling Edge) ;on=Rise (上升沿/Rising Edge)
SW10:S-Filter, off=4ms (高响应) ;on=10ms (低振动)

Mode Sel

模式选择	SW11	SW12
I0 内部自发脉冲 Io internal spontaneous pulse	on	on
电位器调速 Potentiometer speed regulation	on	off
双脉冲 PUL+PUL	off	on
脉冲+方向 PUL+DIR	off	off

## 5.4 参数自整定功能/Parameter self-tuning function

驱动器为开环步进驱动时，驱动器能上电自动匹配电机参数。注意此时不能输入脉冲，方向信号也不应变化，使能信号不能接入。

When the driver is open-loop step-by-step drive, the driver can power up to match the motor parameters automatically. Note that at this time can not input pulse, direction signal should not change, so that the signal can not access.

## 6 保修及售后服务 /Warranty and after-sales service

请保留好包装箱以便运输、储存或需要退回本公司维修时使用。一年保修期：

Please keep the packing box for transportation, storage or need to return to the company for maintenance. One year warranty period:

来自本驱动器使用一年内因为产品自身的原因造成的损坏，负责保修。

From the use of this drive within one year because of the product itself caused by the damage, responsible for the warranty.

不在保修之列：/Not covered by warranty:

不恰当的接线、电源电压和用户外围配置造成的损坏。/Damage caused by improper wiring, power

supply voltage and user peripheral configuration.

无本公司书面授权条件下，用户擅自对产品进行更改。/Without the written authorization of the company, users make changes to the products without authorization.

超出电气和环境的要求使用。/Use beyond electrical and environmental requirements.

驱动器序列编号被撕下或无法辨认。/The drive serial number has been torn off or is unreadable.

外壳被明显破坏。/The outer shell was visibly damaged.

不可抗拒的灾害。/An irresistible disaster.

## 6.2 售后服务 /Aftersales Service

您拨打电话之前，请先记录以下信息：

Before you call, please record the following information:

故障现象/Fault phenomenon

产品型号和序列号/Product model and serial number

安装日期或者生产日期/Installation date or production date